

## Southco® Pawl/Cam Action Latches

## **Industrial Series, Quad Panel Latches**

- Keylocking version includes dust shutter and stainless steel lock cover for scratch resistance
- Tool-operated versions are spring-loaded for grip tolerance and vibration resistance
- Sealed to accommodate NEMA 4 and IP-66 applications
- Pawl indicator shows latch status







## Installation

## Method 1 (assembled)


- 1. Place Sealing Washer onto Latch Housing.
- 2. Tilt latch through mounting hole.
- 3. Install Mounting Nut and tighten to 10 N•m (88.5 in-lbs.) MAX.





# Method 2 (unassembled) Required when Grip does not exceed panel thickness by 9 (.35)

- 1. Remove Screw from Housing.
- 2. Place Sealing Washer onto Latch Housing and place through mounting hole.
- 3. Install Mounting Nut and tighten to 10 N•m (88.5 in-lbs.) MAX.
- 4. Attach Pawl to Latch Assembly. Assure that Pawl Indicator points to Pawl location.
- 5. Install Screw. Tighten to 10 N•m (88.5 in-lbs.) using 10mm hex, No. 2 Phillips or slotted driver.





## **Material and Finish**

DRIVE STUD and HOUSING: (Chrome) Die-cast zinc, chrome plated or (Black) Die-cast zinc, black powder coated. PAWL and SCREW: Low carbon steel, zinc plate, bright chromate. MOUNTING NUT: Die-cast zinc, zinc plate, bright chromate. SEALING WASHER: Polyurethane, black. INTERNAL O-RING: Nitrile, black. INTERNAL SPRING: Spring steel, zinc plate, bright chromate.

### **Keylocking**

LOCK PLUG: Die-cast zinc; Stainless steel cover and nickel plated brass dust shutter. LOCK WAFERS: Brass

FLAT KEY: Brass, nickel plated.

## Product Strength Guidelines


(To assist in your product selection; samples are available for your evaluation.)

Maximum static working load on pawl: 330 N (74 lbs.)

Average ultimate load on pawl: 450 N (101 lbs.)

millimeter (inch)
millimeter

Dimensions without tolerances are for reference only.




## Industrial Series, Quad Panel Latches

## **How to order:**

Product is shipped assembled, layered packed. Sealing Washer and Mounting Nut are included. Alternatively, pawls can be ordered separately.

- 1. Select a Head Style (see table below).
- 2. Select a Finish:
  - **X** = 5 Standard Black Finish
  - **X** = **2** Bright Chrome Finish



## **Keylocking**

**Head Styles** 



## 3. Calculate your Grip

- A. Determine your Total Door Thickness, adding any accessories used:
  - Compressed Sealing Washer (required for NEMA 4/IP-66 applications). Add 0.5 (.02)
  - Pull Tab. Add 2.4 (.093)
  - Padlock Bracket. Add 2 (.08)

B. Add your frame thickness to your total door thickness (see illustration on pg. 1). Find your grip in the pawl table below, and use that pawl type for the YY in the assembly part number. For unassembled version use the letters "UU" for the pawl type and order pawl separate per table below.







Accessories for Quad Latches. See Handbook page 85



## **Keys** (tool operated) **Material and Finish**

Die-cast zinc, bright nickel plate or natural with chemical protective film. (Key E3-8-1 shown)



Order Separately.

vailable 🔽	ASSEMBLY PART NUMBERS												
	NEW	NEW	NEW					NEW					
HEAD STYLES	KEYLOCK	SLOT	8 (.32) HEX SOCKET	7 (.28) TRIANGLE	7 (.28) SQUARE	8 (.32) SQUARE	3 (.11) DOUBLE BIT	5 (.19) DOUBLE BIT	Bellcore 216	Bellcore Electronics	RECESSED SLOT (tamper resistant)	RAILWAY STANDARD	
WW=	40	00	01	02	04	05	06	07	13	19	21	22	
KEY PART NO.	†		8mm (.312) Hex Wrench*	E3-3-1	E3-4-1	E3-8-1	E3-2-1	E3-9-1	E3-12-1	E3-11-1		Operated by RIC Standard* (European Railway)	

<sup>\*</sup>not available from Southco † keylocking version includes 2 keys on ring, other key options available. Call Southco for details.

PAWL TYPE PART NUMBERS													
Pawl Type	YY= 03	YY= 04	YY= 05	YY= 06	YY= 07	YY= 08	YY= 09	YY= 10	YY= 11	YY= 12	YY= 13	YY= 14	YY= 15
Grip+2 (.08)	4 (.16)	6 (.24)	8 (.31)	10 (.39)	12 (.47)	14 (.55)	16 (.63)	18 (.71)	20 (.79)	22 (.87)	24 (.94)	26 (1.02)	28 (1.10)
Pawl Offset	14 (.55)	12 (.47)	10 (.39)	8 (.31)	6 (.24)	4 (.16)	2 (.08)	0 (0)	2 (.08)	4 (.16)	6 (.24)	8 (.31)	10 (.39)
PART NUMBER	E5-6003	E5-6004	E5-6005	E5-6006	E5-6007	E5-6008	E5-6009	E5-6010	E5-6011	E5-6012	E5-6013	E5-6014	E5-6015



Tel: (61) 3 9335 4335

Tel: 0800 1800 380

Australia

Germany

Austria

Hong Kong

Tel: 0800 281 831

Tel: 001 852 3127 1503

### www.southco.com E-mail: info@southco.com

Canada Tel: (1) 905 855 0309 Italy Tel: 800 780 953

China Tel: 800 820 0272 Korea Tel: 0505 777 1234 France Tel: 0800 912 756 Malaysia

Mexico Tel: 001 877 821 0666

Tel: 1800 801 119

ISO 9001: 2000

ISO / TS 16949 ISO 14001

Sweden **United Kingdom Singapore** Spain Taiwan **United States** Tel: 800 18 11016 Tel: 900 968917 Tel: 020 790 366 Tel: 0 080 113 9582 Tel: (44) (0) 1452 715454 Tel: (1) 610 459 4000